## Replacement Parts, cont'd

## 120 DIAL - HEATING

- UNITROL® 110S, 110SCV
- Beige dial, numbered 1 to 9

Robertshaw.



10-078

Uni-Line Part No.

Description

10-078

Beige dial for 110S control

## 1000, 120 DIAL - HEATING

- UNITROL® 1000, UNITROL® 110S
- Brown dial numbered 1 to 9 with "Night-Off" position
- Used on hydraulic models
- Remote mounting

Robertshaw.



10-082

Uni-Line Part No.

Description

10-082

Brown dial for 120 heating control

## 700, 710 DIAL - HEATING

- UNITROL® 7000
- 1-10 green dial used on hydraulic types

Robertshaw.



10-135

Uni-Line Part No.

Description

10-135

Temp. dial on 7000 series hydraulic valves