# W HEATING





## **HEATING ACCESSORIES**

#### **Flame Sensors**

The Robertshaw® Flame Sensor Assembly and Replacement Sensors have high temperature Kanthol sensor rods that will withstand 1800°F (982°C). The sensor rod is 4" long and can be cut and bent to match an original unit. Excellent replacement for most manufacturers' flame sensors.

### **Features and Benefits**

- Includes 30" of Teflon® insulated lead wire with a 482°F (250°C) rating
- Connects to a 1/4" quick connect terminal

# **Specifications**

Part Numbers	Description	Comments
10-227	Replacement S1 Sensor	S1 Sensor has 1/4" quick connect terminal
10-681	Flame Sensor	NA
10-760	Flame Sensor Assembly	Full assembly

# **HEATING ACCESSORIES**



## **Universal Pilot Ignitor Sensor**

The Robertshaw® Universal Pilot Mounting Ignitor Sensor is primarily used with the 712 series intermittent pilot ignition Uni-Kit®. This ignitor and sensor assembly includes mounting bracket, mounting hardware and 24" lead.

## **Features and Benefits**

- Includes all necessary parts for installation
- Quick replacement parts

# **Specifications**

Part Numbers	Description	Length	Comments
1751-729	Universal Pilot Mounting Ignitor Sensor	24" (60cm)	Includes ignitor/sensor assembly, mounting bracket and hardware
1751-749	Universal Pilot Mounting Ignitor Sensor	72" (182cm)	Includes ignitor/sensor assembly, mounting bracket and hardware

Year Limited Warranty

**D42** 

www.robertshaw.com

Customer Service: See Page J21