

Dryer Igniters

DRYER IGNITORS


Uni-Line Part No.	Description	O.E.M. Part No.	Notes
41-021	Ignitor Kit	Maytag LA1021	Kit includes: 1-ignitor, 1-bracket, 1-screw, 1-instruction sheet.
41-311	Ignitor Kit	Whirlpool 279311, Z716K, 239300, 279185, 239233, 239302, 338900, 338899, 343128, 340607, 687399, 685211, WRC23K.	Kit consists of 1-WRC23 ignitor, 2-686608 Nuts, Wire, 1-686833 Bracket, 1-686953 Screw. Individually boxed.
41-590	Ignitor	Whirlpool-Kenmore 686590, Z716, Maytag-Speed Queen 304970.	Silicone carbide ignitor; has a ceramic holder, five inch leads and plug. Individually boxed.
41-700	Ignitor Holder	G.E./Hotpoint WE1X941	Without plug.
41-982	Carborundum Round Style Ceramic Ignitor	Frigidaire 5300600831, G.E./Hotpoint WE4X444, Maytag 303376, Raytheon 55438, Whirlpool 239300, 338899, 338900, 340607	Ceramic ignitor replacement for: Frigidaire & Westinghouse. Replaces Q6Q0831 and 1126982. Whirlpool & Kenmore.




41-982



41-590



41-021



41-311



41-700